

X-COUNTRY

SUMMIT PLATFORM

-
- (A) Read through instructions completely and ensure you understand each step before proceeding*
(B) Check the contents of the kit before fitment and report any discrepancies
(C) Pass instructions onto the customer at the completion of the fitment



Assembly time: 20-45min

IMPORTANT

LOAD RECOMMENDATIONS

- Routinely and regularly check the proper functioning of the system. Check all fixtures at regular intervals.
- Do not use an automatic carwash with system installed.
- Maximum load capacity of the system is 400kg under static conditions.
- Maximum load capacity of the system is 100kg under dynamic including off-road conditions.
- Do not exceed vehicle manufacturers recommended load rating if it is lower than the maximum load capacity specified in this document (i.e., 100kg).
- Ensure any load carried is evenly distributed.
- Actual load on vehicle Roof (Refer to owner's manual) = Weight of Roof rack system / system + Weight of Tray + Weight of cargo.
- Actual load on rack system (Refer to product instructions) = Tray weight + cargo.

WARRANTY INFORMATION

If a defect appears in the system before the end of the warranty period and X-Country finds that the defect is in materials or workmanship, X-Country will, in its sole discretion, either:

1. Repair the system or the defective component of the system free of charge
2. Replace the system or the defective component of the system; or
3. Refund the purchase price of the system to the original purchaser.

X-Country reserves the right to replace defective products or components with products or components of similar quality, grade and composition, where an identical product or component is not available. Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the goods.

The 5 year warranty does not apply where:






1. The system is not installed in compliance with the fitting instructions provided
2. The system is not used as intended or designed
3. Any part of the system is used with other products or components not intended to be used in conjunction with the system
4. The system has been on-sold or assigned by the original purchaser
5. The system has been modified or repaired by someone other than X-Country or an authorized X-Country stockist
6. X-Country cannot establish any fault after inspection of returned product
7. The system has been subject to abnormal conditions, including fire, water, humidity, pressure, stress or similar
8. The defect in the system has arisen due to abuse, misuse, neglect or accident
9. The defect in the system has arisen due to the unlawful or unusual operation of the vehicle to which it is fitted
10. The defect in the system has arisen due to the purchaser's failure to properly assemble, install, fit, maintain or use the system in accordance with the specifications and instructions provided by X-Country.

This warranty does not extend to fair wear and tear. Warranty claims can be made by contacting X-Country directly using the details below. A warranty claim must be accompanied by proof of purchase (such as receipt).

PARTS LIST


HARDWARE

*Quantities for XCS-1512 shown.










TOOLS REQUIRED


- Blade
- 13mm socket wrench
- Cordless drill



PARTS



PLATFORM SIZES




Part Number	Length	Width	Planks	Approx Weight
XCS-1512	1455	1240	6	18.5
XCS-1912	1855	1240	8	22.3
XCS-1514	1455	1380	6	20.3
XCS-914	855	1380	3	9.5
XCS-2112	2055	1240	9	24
XCS-2114	2055	1380	9	26.2
XCS-1212	1255	1240	5	16.1
XCS-1215	1255	1500	5	18.9
XCS-3016	3046	1598	7	23.8

INSTALLATION

1.


- A - Open box and unpack the front/rear and side extrusions.
- B - Open small box and unpack plastic corners and hardware.



TOOL • Blade


2.

- Assemble outside perimeter of the platform in an upright orientation.
- A - Firstly, insert the upper plastic corners into the front and rear extrusions.
 - B - Fit these assemblies into the side extrusions.



3.


Secure plastic corners with 2 x 4x10mm torx screws.



TOOL • T20 torx tool
Torque: 1-2Nm


4.

Carefully turn the platform over. The Summit assembly will now be facing downward.





5.

Assemble the plank plates with 2 x M5 countersunk screws. Be sure to use the same orientation for each end.





6.

Slide in M8 x 16mm hex bolts (x12), into the channels on either side of the platform as shown.



7.

Lower in the plank assemblies and slide across the previously installed M8 x 16mm hex bolts, locating them into the planks as shown. Loosely fix by finger tightening with M8 flanged nuts.





8.

Position the installed planks into their correct positions.


A - Starting at the front of the platform, measure 203mm backward from the front extrusion's channel, to the same position in the channel of the first plank.

B - Measure backward 200mm from the first plank's channel, to the same position in the channel of the following plank. Repeat this for all additional planks.



9.


Use a socket wrench to fix each plank into the positions established above.



TOOL • Socket wrench
Torque: 12-14Nm


10.

Slide M8 x 16mm hex bolts (2x) into the front, rear and side extrusions as shown.



11.

Place the corner brackets into position, sliding them over the hex bolts installed in the previous steps. Fix in place with M8 flanged nuts.





TOOL • Socket wrench
Torque: 12-14Nm

12.

A - Slide 4x M8 x 16mm hex bolts into the channel of the front extrusion.

B - Place the fairing into place over the hex bolts installed previous. Centre the fairing and tighten in place with flanged nuts. *Fairing supplied in Razor kit.




IMPORTANT - Refer to vehicle specific Razor instructions.

TOOL • Socket wrench
Torque: 12-14Nm

13.

Install the lower plastic corners. Fix them in place with countersunk screws.



14.

Attach the Summit Platform to the Razor, according to the vehicle specific instructions.

